

**Ammonium**  
0.5, 1.0, 2.0, 4.0, 6.0, 8.0 ppm

AE307

**Directions for Use:**

1. Take 10 ml of sample in the test jar, provided.
2. Add 10 drops\* of NH 1. Mix thoroughly wait for ten minutes.
3. Transfer the content in small comparator tube provided here.
4. Read the ppm Ammonium as follows:
  - a) Place the comparator tube on the small inner (white) circle, on the colour comparison chart.
  - b) View from the top of the comparator tube to compare the sample colour and the colour around.
  - c) Match the colours by moving the tube from one circle to another.
  - d) Read the ppm Ammonium from the colour chart, after arriving at the correct match.

\* For controlled addition of drops, follow instructions on the dispenser.

Anytime... Anywhere...