

Ammonium
0.05, 0.1, 0.25, 0.5, 0.75, 1.0 ppm

AE317

Directions for use:

- 1) Take 25 ml of the sample in the test jar, provided.
- 2) Add 25 drops* of NH1. Mix thoroughly. Wait for ten minutes.
- 3) Transfer the content in small comparator tube supplied here.
- 4) Read the ppm Ammonium as follows :

- a) Place the comparator tube on the small inner (white) circle, on the colour comparison chart.
- b) View from the top of the comparator tube to compare the sample colour and the colour around.
- c) Match the colours by moving the tube from one circle to another.
- d) Read the ppm Ammonium from the colour chart, after arriving at the correct match.

For controlled addition of drops, follow instructions on the dispenser.

