

## CHLORINE

Chloroscope  
0.05 to 5 PPM

AE - 409

---

### Direction for use:-

- 1) Fill the test jar with the water sample upto the mark.
- 2) Add 3 drops of CL1 and mix well.
- 3) Place the Test Jar in the Comparator slot.
- 4) Read the ppm chlorine as follows.
  - a) Hold the comparator vertically against the light at eye level.
  - b) Match the colour to the colour shade on the comparator.
  - c) Read the chlorine value PPM corresponding to the colour shade.

**ANALYZING**  
**Analysing Waters**  
**Anytime... Anywhere...**

