

Amine
1-20 ppm

AE412

Direction for Use:

1. Take 10 ml of sample in a test jar.
2. Add one spoon of AM 1. Mix well to dissolve.
3. Now drop wise* add AM 2L, counting the number of drops while mixing until the colour changes from Blue to Pale Yellow.

Calculations:

Amine ppm as Cyclohexylamine = 1 X (No. of drops of AM 2L)

* For controlled addition of drops, follow instruction on the dispenser

Note: Only for Boiler condensate water

ANALYZE
Analyzing Waters
Anytime... Anywhere...