

Calcium Hardness
5-100 ppm

AE202

Directions for use:

1. Take 10 ml. of water sample to be tested in the test jar.
2. Add one spoonful (provided herewith) of CH 2.
3. Mix well to dissolve.
4. Then add 10 drops of CH 1.
5. Now drop wise* add CH 3, counting the number of drops while mixing, until the colour changes from red to violet.

Calculations:

Calcium as ppm $\text{CaCO}_3 = 5 \times [\text{No. of drops of CH3}]$

For controlled addition of drops, follow instructions on the dispenser.

Anytime... Anywhere...

