

Calcium Hardness
25-500 ppm

AE212

Directions for use:

1. Take 10 ml of water sample to be tested in the test jar.
2. Add one spoonful (provided herewith) of CH2.
3. Mix well to dissolve.
4. Then add 10 drops of CH1.
5. Now drop wise* add CH3 H counting the number of drops while mixing until the colour changes from red to violet.

Calculations:

Calcium Hardness as ppm $\text{CaCO}_3 = 25 \times (\text{No. of drops of CH3H})$

For controlled addition of drops, follow instructions on the dispenser.

AQUASOL
Analyzing Waters
Anytime... Anywhere...

